
## M4 ROUND




**1.** CUT SHEETROCK. INSERT MUD-PLATE UNTIL FLUSH.



2. MOUNT WITH INCLUDED SCREWS. REMOVE TAPE.



**3.** ENSURE COVER IS FULLY INSERTED AND FLUSH WITH FRAME EDGE.



**4.** APPLY **MUD.** SAND FLUSH TO **FRAME EDGE.** 



6. REMOVE IMMEDIATELY WHILE PAINT IS STILL WET.



5.

PAINT SHEETROCK.

323.934.7779 dmflighting.com