![dmf logo]

DCC

Junction Box Cover

Junction Box Cover Includes

|		
Junction Box Cover	*Bracket Ring (for Cord/Stem Mount only)*	*Bracket (for Surface Mount only)*
Knockout Cover Closed (x3)	*Knockout Cover Open (x4)*	*20mm Screws (x4)* *O-Rings (x2)*

For use with DMF Lighting's DCC Cylinder in open ceiling applications only. Compatible with most 4O octagonal and 4S square junction boxes.

Set Up

1 Configure four sides of Junction Box Cover to desired wiring using Knockout Covers. Junction Box Cover comes pre-installed with two open and two closed Knockout Covers.

Slide off undesired Knockout Cover to remove. Slide on desired Knockout Cover to install. Discard undesired Knockout Covers.

**2** Align Junction Box Cover onto junction box. Secure Cover to junction box with two (2) screws.


4S Square
Junction Box

4O Octagonal
Junction Box

dmf Lighting®

Have a question? Contact us!
800.441.4422 | info@dmflighting.com

Installation for Surface Mount Cylinder

1 Discard Bracket included with Cylinder and Bracket Ring included with Junction Box Cover. Utilize Bracket included with Junction Box Cover.

**2** Align Bracket to Junction Box Cover. Secure Bracket to Cover with two (2) screws.

3 Complete Surface Mount Cylinder installation following instructions from *DCC Surface Mount LED Cylinder Installation Instructions*.


Installation for Cord / Stem Mount Cylinder

1 Discard Bracket included with Junction Box Cover. Utilize Bracket included with Cylinder and Bracket Ring included with Junction Box Cover.

2 Align two (2) screws with two (2) O-rings into Bracket and Bracket Ring.

3 Align Bracket and Bracket Ring to Junction Boc Cover. Secure Bracket to Cover with two (2) screws.

4 Complete Cord / Stem Mount Cylinder installation following instructions from appropriate *DCC LED Cylinder Installation Instructions.*